

OLE fix for SheetWorks V10 Embedded Version
Installation Notes

1. Make a backup copy of the cadcam.exe; fwres11.dll and sldworks.dll, in the \fabriwin or \ap100us\fabriwin folder.
2. Make a backup copy of the “transfaddin.dll” in the \windows\system32 folder.
3. Copy the cadcam.exe; fwres11.dll and sldworks.dll into the \fabriwin or \ap100us\fabriwin folder.
4. Copy of the “transfaddin.dll” in the \windows\system32 folder.
5. Register the transfaddin.dll, using the “regsvr32 transfaddin.dll” from command line.
6. Run the new CADCAM.EXE from the \fabriwin or \ap100us\fabriwin folder.