

AMNEST Version 4.0 Update for AP100US 2010 (.PRT and MStoolInfo.dll): 10/09/09

## NOTE

This AMNEST V4.0 update is for users who are using AP100US 2010 .PRT files with Amnest V4.0 for laser nesting as well as Special tools (.SPT) files from AP100US 2010 with Amnest V4.0 for punch nesting and updates the Import Special Tool File Utility (Amnest).

Ensure that Amnest software is closed and exited before installing the patch file. Also, it is always a good practice to backup your original files before installing/updating with new files. This update is designed to be installed to default installation path structure of Target Drive Letter\Program Files\AMNEST\Ample\FMS\Bin\ folder.

## Installation Instructions (Win 2000, XP, Vista):

- 1) Run PRT and MStoolinfo 2010.exe to install design\_geom.dll (9/1/09), dxfigs.dll (9/4/09), DxfigsWrapper.dll (9/4/09), ExpImpDxfDwg.dll (9/4/09), FWFileConverter.exe (9/4/09), mstoolinfo.dll (9/14/09), OldFWIO.dll (9/4/09), StorageMgr.dll (11/20/07), and Zw\_u.dll (9/1/09) to C:\Program Files\Amnest\Ample\FMS\Bin\ folder. Please substitute your hard drive letter for "C" as required.
- 2) When the Winzip Self-Extractor opens, ensure that "Overwrite files without prompting" is checked.
- 3) Select the Unzip button to unzip the files.
- 4) Double-click Amnest icon on the desktop to run Amnest.

## CONTACT INFORMATION:

Amada America Inc.  
7025 Firestone Blvd.  
Buena Park, CA 90621  
(800) 626-6612

For more information about Amada and its line of products, visit the website at [www.amada.com](http://www.amada.com).

Microsoft Windows 2000, XP, and Vista are registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. Amnest is a trademark of Amada America Inc.